

**ENR 4. SISTEMAS DE RADIO-AYUDAS A LA NAVEGACION**  
 ENR 4. RADIO NAVIGATION AIDS / SYSTEMS

**ENR 4.1 RADIO-AYUDAS A LA NAVEGACION EN RUTA**  
 ENR 4.1 RADIO NAVIGATION AIDS — EN-ROUTE

NOMBRE DE LA ESTACION /	ID	FRECUENCIA /	HORAS DE OPERACION /	COORDENADAS /	OBS
NAME OF STATION	ID	FREQUENCY	HOURS OF OPERATION	COORDINATES	RMK
1	2	3	4	5	6
BARAHONA VOR / DME	BHO	112.0 MHZ	H24	18° 15' 16"N 071° 07' 49"W	
PUNTA CAUCEDO VOR / DME	CDO	114.7 MHZ	H24	18° 25' 59"N 069° 40' 02"W	
CABO ROJO VOR	DCR	114.3 MHZ	H24	17° 55' 54"N 071° 38' 54"W	
LA ROMANA VOR / DME	LRN	116.20 MHZ	H24	18° 27' 14"N 068° 54' 43"W	
PUNTA CANA NDB	PCA	425 KHZ	H24	18° 33' 51"N 068° 22' 17"W	
PUNTA CANA VOR / DME	PNA	112.7 MHZ	H24	18° 34' 02"N 068° 23' 00"W	
PUERTO PLATA NDB	PPA	450 KHZ	H24	19° 45' 09"N 070° 34' 13"W	
PUERTO PLATA VOR / DME	PTA	115.1 MHZ	H24	19° 45' 33"N 070° 34' 14"W	
SANTIAGO VOR / DME	SGO	114.9 MHZ	H24	19° 24' 26"N 070° 36' 14"W	
SAN ISIDRO VOR	SIS	114.5 MHZ	H24	18° 30' 16"N 069° 45' 45"W	
HIGÜERO NDB	HGR	300 KHZ	H24	18° 34' 53"N 069° 58' 49"W	
CATEY VOR / DME	DCY	115.8 MHZ	H24	19° 16' 14"N 069° 44' 27" W	