

**ENR 4. SISTEMAS DE RADIO-AYUDAS A LA NAVEGACION**  
ENR 4. RADIO NAVIGATION AIDS / SYSTEMS

**ENR 4.1 RADIO-AYUDAS A LA NAVEGACION EN RUTA**  
ENR 4.1 RADIO NAVIGATION AIDS — EN-ROUTE

NOMBRE DE LA ESTACION /	ID	FRECUENCIA /	HORAS DE OPERACION /	COORDENADAS /
NAME OF STATION	ID	FREQUENCY	HOURS OF OPERATION	COORDINATES
1	2	3	4	5
PUNTA CAUCEDO VOR / DME	CDO	114.7 MHZ	H24	18° 25' 59"N 069° 40' 02"W
CABO ROJO VOR / DME	DCR	114.3 MHZ	H24	17°55'56"N 071°38'52"W
LA ROMANA VOR / DME	LRN	116.20 MHZ	H24	18° 27' 14"N 068° 54' 43"W
PUNTA CANA VOR / DME	PNA	112.7 MHZ	H24	18° 34' 02"N 068° 23' 00"W
PUERTO PLATA VOR / DME	PTA	115.1 MHZ	H24	19° 45' 33"N 070° 34' 14"W
SANTIAGO VOR / DME	SGO	114.9 MHZ	H24	19° 24' 26"N 070° 36' 14"W
SAN ISIDRO VOR / DME	SIS	112.4 MHZ	H24	18° 30' 12.19"N 069° 45' 57.11"W
HIGÜERO NDB	HGR	300 KHZ	H24	18° 34' 53"N 069° 58' 49"W
CATEY VOR / DME	DCY	115.8 MHZ	H24	19° 16' 14"N 069° 44' 27" W

OBS / RMK
<b>6</b>
<b>RESTRICCIONES PARA CABO ROJO VOR/DME (DCR) / CONSTRAINTS FOR CABO ROJO VOR/DME (DCR)</b>
<b>VOR:</b> 000-080 / byd 25 / all dist and alts; 130-155 / byd 25 / blo 9000' ; 195-250 / byd 25 / all dist and alts.
<b>DME:</b> 000-045 / byd 25 / all dist and alts; 045-055 / all dist and alts; 055-080 / byd 25 / all dist and alts; 130-155 / all dist and alts; 350-000 / byd 25 / all dist and alts.
<b>VOR/DME:</b> 080-130 / byd 25 / blo 9000'; 155-165 / byd 25 / blo 9000'.